



METO[®]
your retail label expert

METO[®]
Classic L



METO[®]
Classic XL




METO[®]
Classic XL
Giant




STEP 1
Open up the front plate and
press the handle to lift
the ink roller



STEP 2
Remove the ink roller
insert new ink roller



STEP 3
Clip the new ink roller upright in to
the holder




STEP 4
Release the handle and
clip the front plate into the holder



STEP 5
Pull out pointer and turn
to the selected digit



STEP 6
Push back pointer to original
position before printing



Find your language on
meto.com/hls/support
Visit us on Youtube



METO®
Classic L

METO®
Classic XL

METO®
Classic XL
Giant

METO®
your retail label expert

STEP 1
Push in label roll, label side facing up.



STEP 2
Slide down base plate catches until base plate drops open.



STEP 3
Pull out 20cm of the label roll, and feed between the roller and the top of the base plate.




STEP 4
Close the baseplate on the tool till it snaps in.



STEP 5
Feed the labels through the top of the transport unit until labels appear at the bottom of the unit.



STEP 6
Press the handle several times until the label tape becomes visible at the end of the transport plate.



www.meto.com
Visit us on
Youtube